


RF AMP
1st MIXER
2nd MIXER
IF AMP
DET
S-METER
SQ CONTR.
AUDIO AMP
ALC CONTR.
MIC AMP.
RF DRIVER
RF POWER AMP
L.P. HARMONIC FILTER
PRE AMP
TX DOUBLER
MULTI PLEXER
PLL
R/TX VCO
R/TX REGU.
R/TX SW
SP1 SPEAKER 0.2W 8 ohm
JK1 EXT SP.
JK3
JK2 ANT
FUSE 2A
13.2V DC
DC POWER CORD
POWER SW
1. MIC INPUT
2. GROUND
3. P.T.T.
4. GROUND
5. SP. GROUND
MIC
PUSH TO TALK
MICROPHONE ASSEMBLY



(Main P.C. Board)